

# POWER SNAPPY DAILY CHECKLIST

This check must be made by the Power Snappy operator daily at the start of the shift. Certain items listed are not included on some models. Check all items applicable to unit noted on this sheet.

Week beginning: \_\_\_\_\_ 20\_\_\_\_\_

Shift No: \_\_\_\_\_

Serial No: \_\_\_\_\_

## Check the appropriate box:

OK, no attention needed

Needs Attention (Give notes on back)

		MON	TUE	WED	THR	FRI	SAT	SUN
OPERATOR	Check that the Power Snappy Operator's Manual and safety decals are in place and legible.	OK	OK	OK	OK	OK	OK	OK
	Ensure that operator has reviewed the Power Snappy Operator's Manual.	OK	OK	OK	OK	OK	OK	OK
	Ensure that the operator is fully comfortable operating the Power Snappy and is both physically and mentally fit to operate the Power Snappy.	OK	OK	OK	OK	OK	OK	OK
GENERAL VISUAL CHECKS	Scaffold components not rusted.	OK	OK	OK	OK	OK	OK	OK
	No damaged welds or cracking.	OK	OK	OK	OK	OK	OK	OK
	No bends or kinks in scaffold components.	OK	OK	OK	OK	OK	OK	OK
	Coupling pins straight and free of debris.	OK	OK	OK	OK	OK	OK	OK
	Casters are in good condition, free of debris and securely in place.	OK	OK	OK	OK	OK	OK	OK
	Guardrails in good repair and components in place.	OK	OK	OK	OK	OK	OK	OK
	Clearance between the scaffold and power lines is adequate.	OK	OK	OK	OK	OK	OK	OK
	Scaffold is free from snow, ice, or other slippery material.	OK	OK	OK	OK	OK	OK	OK
	Debris on the scaffold is not excessive and is securely in place.	OK	OK	OK	OK	OK	OK	OK
	Ensure that all nuts, bolts and snap pins are secure.	OK	OK	OK	OK	OK	OK	OK
POWER SNAPPY SPECIFIC	All four of the guardrail hinge pins are in place.	OK	OK	OK	OK	OK	OK	OK
	Armbraces are at identical heights and the walkboard is level.	OK	OK	OK	OK	OK	OK	OK
	G-Pins are fully engaged and locked into the scaffold frame. Optional: For additional safety, insert the snap pin provided through the armbrace and the frame and lock it in place.	OK	OK	OK	OK	OK	OK	OK
	Auto Lock feature is properly engaged and the drive wheels are locked in place. The Power Snappy should not move if force is applied to the scaffold frame.	OK	OK	OK	OK	OK	OK	OK
	Power Snappy Banded Walkboard is being used.	OK	OK	OK	OK	OK	OK	OK
	Walkboard is nested in the alignment pins.	OK	OK	OK	OK	OK	OK	OK
	All four walkboard hold down clips are engaged.	OK	OK	OK	OK	OK	OK	OK
	Check electrical connections to the battery box and motor controller.	OK	OK	OK	OK	OK	OK	OK
	Check wiring for any signs of fraying.	OK	OK	OK	OK	OK	OK	OK
Ensure outriggers are installed properly. (Power Snappy L)	OK	OK	OK	OK	OK	OK	OK	
OPERATING	Switch the key to the "on" position.	OK	OK	OK	OK	OK	OK	OK
	Close and lock the guardrail door upon entering the Power Snappy.	OK	OK	OK	OK	OK	OK	OK
	Press the power button and make sure there are no errors coming from the controller.	OK	OK	OK	OK	OK	OK	OK
	Ensure the operator is facing the proper driving direction.	OK	OK	OK	OK	OK	OK	OK
	Double check that the path is clear and there are no driving hazards in the area.	OK	OK	OK	OK	OK	OK	OK
	Slowly push the joystick in the direction you like to travel.	OK	OK	OK	OK	OK	OK	OK
OPERATOR'S INITIALS								
SUPERVISOR'S OK								

CAUTION - If the Power Snappy is found to be in need of repair on in any way unsafe, or contributes to an unsafe condition, the matter shall be reported immediately to the designated authority, and the Power Snappy shall not be operated until it has been restored to safe operating condition.

If during operation, the Power Snappy becomes unsafe in any way, the matter shall be reported immediately to the designated authority, and the Power Snappy shall not be operated until it has been restored to safe operating condition.

Do not make repairs or adjustments unless specifically authorized to do so.

